



**DASH**

# SINGER

Wi-Fi Chime Kit

Instant alerts sound out from the Singer when your Dinger doorbell is rung. The Singer offers several different customizable ringtones made available through the Dash app available on the App store and Google Play store.



### Plug & Play

Works with the Dash App



### Mobile Application

Download for free on Android & iOS




### Easy to Install

Just need a Wi-Fi connection



### Multiple Ringtones


Customizable straight from within the app



## Stay Close To What Matters.

With Cloud service, you will have access to what you care as long as Internet is available. You can record motion videos on Cloud and play back anytime anywhere.





## Specifications

### Audio

Audio Output: Built-in Loudspeaker  
Ring Tone: Multiple optional ring tones  
(setting on APP)

### Operation Mode

Reset/WPS Button: 1  
Indicator Light: 1

### Network

Wi-Fi: IEEE802.11b/g/n  
Dash app: iOS, Android

### General

Installation: Surface  
Voltage: 90-240Vac  
Working Temperature: 14° ~ 122°F (-10° ~ +50°C)  
Relative Humidity: 20% ~ 95%RH  
Dimensions: 3.9x2x1.3 in (99x52x33.7 mm)  
Weight: .66 lbd (0.3 Kg)

