### About Laser Shark:

RTI is pleased to offer dealers the ability to create their own custom button labels for compatible RTI products (listed below). The powerful yet simple to use Laser Shark<sup>®</sup> software allows you to use almost any font or graphic, to insure the ultimate in intuitive control for your clients.

#### **Features**

- Allows easy customization of button keycap labels on certain RTI products
- Select from almost any font type, language, symbol or graphic image
- Compatible with RK1-2, RK1-4, RK1-8, RK3-V, RKM-1+, T1-B, and T3V+
- One click direct ordering via the Internet
- Software is free of charge and available to RTI dealers only

### Laser Shark Software Help Topics:

### **Managing Order Files**

- Choose *New* from the menu bar to create a new order
- Choose *Open* from the menu bar to open a previously saved order file (\*.lsd)
- Choose *Save* from the menu bar to save an order (\*.lsd)

#### **Managing Devices**

- To add devices to an order:
  - Click the *Add* button on the *Devices* menu bar
  - Select the appropriate device type from the *Add* button pull-down

- Note: each device will require an Order Code before the order can be placed. Visit <u>http://www.rticorp.com/dealers/lasershark\_dealer.html</u> to place an order and receive Order Codes.
- To delete devices from an order:
  - Select the device to be deleted
  - Click the *Delete* button on the *Devices* menu bar
- To rename a device:
  - Select the device to be renamed
  - Click on the device name of the selected device to make the device name editable.
  - Enter the new device name and hit *Enter, Tab* or click elsewhere.

# Adding Text to a Button

- With a device selected, click on a button in the preview area (click and drag to select multiple buttons at once)
- In the property sheet to the right of the preview area, set *Content Type* to *Text*
- Select the *Label* property and enter the desired text
- Hit Enter to add additional lines of text
- Hit Ctrl-Enter, Tab or click outside the text entry box to end text entry
- Set font and alignment properties as desired

## Adding an Image to a button

- With a device selected, click on a button in the preview area (click and drag to select multiple buttons at once)
- In the property sheet to the right of the screen, set *Content Type* to *Image*
- Select the *Image* property and click the "…" button to the right of the property to launch a file open dialog
- Browse to the desired image and hit the **Open** button
- Notes regarding images:
  - Supported file types: *BMP, JPG, GIF, TIF, and PNG*

- Laser etching requires the image to be black and white only. If it's not already, Laser Shark will convert the image to black and white. If you want more control over the conversion process use an image editor and convert the image manually before using in Laser Shark.
- o Larger images will produce better results and smoother edges than smaller images
- Please use reason when choosing images since images with too much detail may not produce the results you desire when etched on the button.

## **Copying and Pasting Buttons**

 Right-click on a button to copy or paste the button, the row of buttons, or the section of buttons, depending on the device type.

## **Placing an Order**

- Completely fill out the **Order Information** section
- Enter an Order Code for each device in the order, ensuring to take the Quantity value for each device into account. If you don't have order codes, visit
   <u>http://www.rticorp.com/dealers/lasershark\_dealer.html</u> to place an order and receive the codes.
- Click the *Export Order* button on the menu bar to export the order to an \*.lsdOrder file.
- Email the exported order file to <a href="mailto:LaserShark@RTICorp.com">LaserShark@RTICorp.com</a>